

DOUBLE USB WALL PLUG MANUAL



10.35.0010



Please read and follow these instructions to avoid damaging the item. We do not cover damage that may result from improper use of the article or non-compliance with the safety instructions.

Important safety advice:

- Read instructions before use.
- To protect against electric shock or personal injury, do not handle the electrical outlet or cables near any liquid.
- Do not expose the plug to extreme temperatures. Must be used in moderate environments.
- Do not handle the product in any way other than as instructed in this manual.
- Do not attempt to repair, any repair or service should be performed only by qualified personnel.
- The product may not be opened or its components modified. The manufacturer is not responsible for any radio or television interference caused by unauthorized modifications.
- The device is not a toy. Do not allow children to play with it, or allow children to introduce foreign objects.
- Never clean the surface of the device with solvents, paint thinners, cleaners or other products.
- Save these instructions.



Use:

This product is used as a power outlet and has 2 additional USB ports for charging electronic devices with a voltage of 5V DC/2.4A.

It may only be used and installed in the manner described in this manual. This product is not intended for use by children or people without experience or knowledge of its use, unless instructed and supervised by a person responsible for its safety.

Composition:


- 1 x Power socket schuko
- 1 x Fixing plate
- 1 x Embellisher
- 2 x Screws

Technical details:

Power socket schuko: connection by means of a 3 wire electric cable (15A, 250V AC): phase conductor (L), neutral conductor (N) and ground point (⊕).

USB outputs: DC 5V and 2.4A maximum, either one alone or between the two.

Dimensions:



Installation:



In case of any doubts, the installation should be carried out by qualified personnel.


1. Use a voltage tester to verify the voltage given on the phase conductor (L), usually black, brown or gray, **before installing** the product.
2. Switch off the power supply before installing the product. Start the installation of the socket only after making sure that there is no voltage in the cables.

3. Install the double USB plug on the wall:

- Place the fixing plate (1) on the wall with the ↑UP in the upper part and screw it with the two screws included in the product.
- Connect the three cables to the schuko socket (2) and secure with the corresponding screw:
 - L: brown, black or grey cable.
 - N: blue cable.
 - ⊕: green or yellow cable.

* The colors of the specified cables are the most common.

- Embed the schuko socket with the cables connected to the wall mounting plate (1).
- Place on both (1) and (2) the embellisher (3) leaving the ↑UP of the back side in the top.



Environmental awareness:



In accordance with European waste regulations 2002/96/EG, this symbol on the product or its packaging indicates that this product may not be treated as household waste. It must be ensured that this product is disposed of correctly; it will avoid possible negative consequences for the environment and human health, which could otherwise be caused by improper handling of the waste from this product.

Product certifications:



RoHS

